


FA-35 MOTOR ASSEMBLY AND PARTS LIST



The part numbers with () are included in the Ass'y parts written above them.

No.	Part No.	Part Name	Q'ty	Price
1	TQ01136	Spindle Arbor	1	
3	TQ01137	Gear Case	1	
4	TQ00858	Bearing Holder	1	
5	TP00513	Spring Washer M5	10	
6	TQ00859	+ Screw 5 X 10	4	
7	TP01632	Ball Bearing 6203Z	1	
8	TQ00860	Collar	1	
9	TQ00661	Spiral Gear (B)	1	
10	TP18356	Retaining Ring	1	
11	TP06626	Ball Bearing 6200	1	
12	TP17449	+ Screw 5 x 60	6	
13	TP17481	Ball Bearing 60B	2	
14	TQ00862	Pinion	1	
15	TP06393	Sunk Key 3 X 3 X 5	1	
16	TQ00863	Spiral Gear (A)	1	
17	TQ00864	Bearing Bracket	1	
18	TQ00865	Wind Shield Plate	1	
19	TQ00866	Spacer	1	
20	TP17438	Ball Bearing 6200Z	1	

No.	Part No.	Part Name	Q'ty	Price
21	TB00673	Armature Ass'y (100V)	1 set	
	TB00820	Armature Ass'y (115V)	1 set	
	TB00821	Armature Ass'y (230V)	1 set	
22	TP02714	Ball Bearing 608Z	1	
	TB00674	Field Ass'y (100V)	1 set	
	TB00822	Field Ass'y (115V)	1 set	
23	TB00823	Field Ass'y (230V)	1 set	
	TQ00867	Brush Cap	2	
24	TQ00867	Brush Cap	2	
25	TB00598	Brush Ass'y	1 set	
26	TQ00868	Brush Holder	2	
27	TQ00869	Insulation Washer	2	
28	TP12786	Side Handle	1	
29	TQ00870	Stator Spider	1	
30	TP16481	Condenser	1	
31	LP30251	+ Screw 4 X 16	2	
32	TP13382	Cable Clamp	1	