


# 12 HA06-1322 ASSEMBLY

## **⚠ WARNING**

This diagram is for your reference only. Do not attempt to service or repair the Tool.  
Do not take the Tool apart. Contact an authorized Nitto dealer for all service and repair of the Tool.  
Improper service and repair can cause accidents and service injuries.  
Never attempt to modify the Tool. Never attempt service or repair the Tool yourself.



# 13 HA06-1322 PARTS LIST

The Part number with ( ) are included in the Ass'y parts written above them.

No.	Part No.	Part Name	Q'ty	Price
1	TB04990	Inner Cover Ass'y	1set	
2	(TQ06572)	Label Caution Inner Cover	1	
3	TP08301	Nut M24 Special	1	
4	TP08300	Upper Plate	1	
5	TP08299	Spring 25.5×83×96.5	1	
6	TP08313	Back-up Ring 25×33×1.25 T2	2	
7	TP08312	Y Packing UHS-25	2	
8	TP06258	Hex. Socket Set Screw With Flat Point 5×8	4	
9	TQ04515	Cap	1	
10	TP08303	Piston	1	
11	TP08309	Y Packing US-67	1	
12	TP08310	Back-up Ring 67×82×2 T2	1	
13	TP08308	Ram	1	
14	TP08307	Bushing	1	
16	TP06397	Hex. Socket Set Screw With Cup Point 6×8	1	
18	TP09458	Hex. Socket Set Screw With Cone Point 8×14	2	
19	TP08520	O Ring P-42	1	
20	TP08305	Stripper	1	
22	TA99036	Lock Nut Ass'y	1set	
23	TP07009	Urethane Washer 31×40×3.1	1	
24	TB04989	Cover Ass'y	1set	
25	(TQ06571)	Label Caution	1	
26	(TQ03540)	Label Model Number	1	
27	TQ06476	Push Switch MB2011 L/B	2	
28	TP13750	Bracket	1	
29	TP05119	Pan Head Screw 5×8	6	
30	TP01460	Hex. Socket Head Cap Screw 8×20	2	
31	TA94558	Push Rod Ass'y	1set	
33	TP08139	Hex. Nut M2.3	2	
34	TP07785	Spring Washer M2.3	2	
35	TP11442	Limit Switch	1	
36	TP08135	Glass Wanice Cross 28×20	1	
37	TP07783	Limit Switch Cover Black	1	
38	CA94119	700R-3P Cap Ass'y	1set	
39	TP07793	Set Screw	1	
40	TP07792	Nipple PT3/8×PT3/8 Special	1	
41	TQ03545	Conical Spring Washer M6	4	
42	TP12928	Cord Sleeve	1	
43	TP12929	Stopper	1	
44	TQ03522	Grip	1	
45	TP08188	Insulating Sleeve Plug 170887-1	2	
46	TP08186	Connection Plug 170020-1	2	
47	TP08189	Insulating Sleeve Receptacle 170889-1	2	
48	TP08187	Receptacle 170021-1	2	
49	TP02419	Pan Head Screw 6×10	1	
50	TP07784	Pan Head Screw 2.3×15	2	
57	TP01644	Hex. Socket Head Cap Screw 6×12	4	

No.	Part No.	Part Name	Q'ty	Price
58	TP09433	Pan Head Screw 4×10	3	
59	TA94434	Metal Concent Adaptor Ass'y	1set	
	(TP08712)	Metal Concent Adaptor NCS-163-AD	1	
60	TQ03526	LR Cap Screw 8×12 Special	4	
61	TP03508	Spring Washer M5	6	
62	TB04925	Switch Cover Ass'y	1set	
63	(TP08411)	Label Switch	1	
64	TQ06612	Plate Model Number	1	
65	TP05136	Drive Rivet No.2×4.8	4	
66	TQ03855	Oblong Washer	4	
67	CP01181	Ball 5/32	1	
68	TP05154	Drain Screw	1	
69	TP07843	Hex. Socket Set Screw With Cup Point 8×8	1	

## Accessories

	Part No.	Part Name	Q'ty	Price
17	TA92089	Sub Handle Ass'y	1set	
51	TA93778	Switch Cord Ass'y	1set	
52	(TP07795)	Metal Concent Plug NCS-163-PM	1	
53	(TP07794)	Cabtyre Cord Vinyl	1	
54	(TP07796)	Metal Concent Plug NCS-163-P	1	
55	TP05184	Ultra-high Pressure Hose	1	
56	CA94118	700R-3S Cap Ass'y	2sets	
	TP06012	Spanner	1	
	TP10198	Tool Box	1	
	TP01939	Hex. Socket Screw Key 4	1	
21	TJ06676	D Punch 22	1	
32	TJ06677	D Die 22	1	
	TQ06573	Instruction Manual	1	